



Tech Info Library

LaserWriter: Windows PS Header Not Loaded Error (11/94)

Article Created: 17 November 1994

TOPIC -----

I am trying to print from a Power Macintosh with SoftWindows to a LaserWriter Select 360 printer. However, every time I try to print from within Windows I get a "PS Header Not Loaded" error. Is this a problem with the driver?

DISCUSSION -----

The only time I have seen this symptom, and it happens in Windows on a true Windows computer too, is when the "Send Header With Each Job" option is unchecked.

Changing PostScript Header

- 1) Open the Printers control Panel
- 2) Click on Setup
- 3) Click on Options
- 4) click on the box that reads "Send Header With Each Job". When an 'X' appears in the box, it sends the header with each job.

Make sure the box is checked and try printing again.

I have tested SoftWindows with system software 7.5, and it prints fine from Windows. In addition, I unchecked the "Send Header With Each Job" box and tried to print. I did not get the error message that you did on the screen, instead the error message was printed and I received a general "PostScript Error" from PrintMonitor. So, checking the box should correct the problem.

Support Information Services
Copyright 1994, Apple Computer, Inc

Keywords: kwindows

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 16777