



Tech Info Library

LocalTalk PC Card: How to Configure It for TOPS

This article last reviewed: 25 May 1990

TOPIC -----

TOPS documentation claims support for the LocalTalk PC Card. I want to communicate through the card from a PC using TOPS. Although TOPS claims support for the card, their technical support group could not tell us how the card must be configured. Can you help?

DISCUSSION -----

TOPS Technical Support told us how to configure their software for use with the LocalTalk PC Card. The most common problem encountered in this situation is that some required software is not included with the LocalTalk PC Card. AppleShare PC and the LocalTalk PC Card were originally shipped as a package. They are now separate items.

Users of the TOPS card should have an AUTOEXEC.BAT file that looks like this:

```
ALAP
PSTACK
TOPSTALK
TOPSKRNL
```

Users of the LocalTalk PC Card should have an AUTOEXEC.BAT file that looks like this:

```
LSL
LTALKP
ATALK
COMPAT
TOPSTALK
TOPSKRNL
```

Note that the first two files for the TOPS card user are replaced by the first four files shown for the LocalTalk PC Card user. The .COM files associated with the names above are included with AppleShare PC.

After starting up with the above AUTOEXEC.BAT file on disk, run TOPS menu and proceed as described in the TOPS documentation.

Copyright 1990 Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 5573