

Tech Info Library

ISDN: Troubleshooting Using NT-1 Lights (3/96)

Article Crea	ted: 6 March 19	96	
TOPIC			
	provides a tab	le to help troubleshoot NT	-1 (Network Terminator)
DISCUSSION -			
These lights		troubleshoot your ISDN li	er, U Loop Back, and S/T&U. ne. Below is a table
Begin_Table			
Normal Light			
	State	Reason	Check
Power	On Off	Power is on Line isn't being tested Line is ready for use	
Other Light			
	State		Check
	Off	There is no AC power	Power cord, AC wall jack.
U Loop Back	On/blinking	Line is being tested	Contact local phone company to see if line is actually being tested.
S/T&U (ma	Fast blinking ny blinks/sec)	Line is attempting to communicate with central office	If light then goes out, the line is ready to be used. If the light stays on,

then check both cables coming out of the NT-1. If the problem continues, contact your phone company.

S/T&U On steady Line is not hooked up

properly

Check cable going

from wall jack to

the NT-1.

S/T&U Slow blinking Line is not hooked up

(1 blink/sec) properly

Check cable going from NT-1 to the

ISDN device.

End_Table

Copyright 1996, Apple Computer, Inc.

Keywords: hts

This information is from the Apple Technical Information Library.

19960307 07:57:58.00

Tech Info Library Article Number: 19423