

## Tech Info Library

## **ImageWriter II Initial Checks**

This article last reviewed: 2 November 1988

CHECK

NOTE: Remove the Option Card if one is installed. Check the DIP switches after removal. SW2-4 should be open/off with the card out.

This initial check table deals with minor problems such as a loose cable, bad ribbon cartridge (color or black), incorrectly set DIP switches, etc. The items on this list should always be checked before you begin actual troubleshooting.

## INITIAL CHECKS

SYMPTOM

problem

Prints okay for a

Check for the problems below. If your problem isn't listed in or solved by the initial checks, search on IMAGEWRITER II GENERAL TROUBLESHOOTING.

SIME TOM	CHECK
Error lamp blinks	-Is carrier cover securely in place? -If left margin error occurs while printing, it may be a software problem: try other software.
Select off, Error on	-No paper or paper improperly inserted?
No printing or garbled printing	-Is the interface cable between the printer and computer loose or disconnected? -Check DIP switches: SW2-1 and SW2-2 should be closed for 9600 BPS SW2-3 should be open for DTR handshaking (DTR is a (popular form of data flow control; for more info on flow control search on HTS and FLOW CONTROL). SW2-4 should be open if no option card is installed and closed if an option card is installed.
Software-specific	-Try a known good piece of software.

-Contact the Software Manufacturer to see

-Set DIP switch 2-3 to the correct serial protocol.

if the program supports the IW II.

while then garbage -Check that cable is securely installed.

Overprinting -Check that the program being used

is set for the correct line spacing

and line length.

Light printing -Change ribbon cartridge.

-Try different settings of the

impression control lever

(four positions).

Copyright 1988 Apple Computer, Inc.

Keywords: hts

-----

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 1403