



Tech Info Library

LaserWriter & LaserWriter Plus: Change Cleaning Felt Regularly

This article last reviewed: 21 July 1988

Some users have noted a problem with the Canon engine in both the LaserWriter and LaserWriter Plus that could lead to trouble without proper maintenance.

Under the green cover, which hides the fuser roller, are four orange rubber "fingers" that touch the roller. As toner builds up on these fingers, it crystallizes and becomes abrasive. This residue then scrapes off the teflon coating on the roller.

When the teflon coating wears through, toner no longer fuses to the paper at that position. (The finger on the far right as you face the roller seems to be affected the most.) The only fix at this point is to completely replace the fuser assembly, which is a very expensive solution.

You can prevent this from happening by ALWAYS replacing the cleaning felt (the green plastic strip that comes packed with the toner cartridge) every time the toner cartridge is replaced.

Copyright 1988 Apple Computer, Inc.

Keywords: <None>

=====
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 3125