



Tech Info Library

StyleWriter: Troubleshooting Ink Cartridge Problems

Article Created: 9 December 1991

Article Last Reviewed:

Article Last Updated:

TOPIC -----

These print quality problems have been reported when replacing the StyleWriter Ink Cartridge:

- No print
- Light print
- White lines
- Smudging

DISCUSSION -----

If your StyleWriter exhibits any of these symptoms, here are some things to check:

- Ensure that the orange tape and orange cap have been removed from the ink cartridge.
- Ensure that the black rubber boot isn't missing or twisted.

The rubber boot is located below the home position of the ink cartridge.

- Ensure that you have powered down the StyleWriter using the Power button.

Powering down the StyleWriter with the Power button caps the ink cartridge. Removing the Power Adapter Cord from the back of the printer will not cap the ink cartridge and may result in poor print quality.

- Ensure that you purge the ink cartridge five times before swapping the cartridge and/or modules.

Apple now recommends purging the ink cartridge five times to relieve any obstructions that may have worked their way into the nozzles during transit.

To perform a manual purge:

1) Turn the StyleWriter off with the Power button. (The printer must be turned off.)

2) Press and hold the Ready button.

3) Press the Power button once and release both buttons at the same time.
Copyright 1991, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 9600