



Tech Info Library

Alternating Cursor: Macintosh Can't Boot (11/94)

Article Created: 13 October 1993

Article Reviewed/Updated: 02 November 1994

TOPIC -----

After starting the Macintosh, it draws a menu bar with no text, freezes, and then the cursor changes between the watch and arrow continuously. The Macintosh never completes the startup sequence. The Macintosh can't boot from a System 7.x floppy disk, but can boot from a System 6.x floppy disk. Booting with extensions off or zapping parameter RAM doesn't help either.

DISCUSSION -----

The cause of this is incorrect window coordinates in the Finder. The Finder stores the top-left and bottom-right coordinate of each window. Should, for some reason, the bottom-right coordinate of a window be to the left or top of the top-left coordinate, the Finder will get very confused. You'll then see the alternating wristwatch and arrow cursor.

The solution to this problem is to restart with the Option key held down. This forces the Finder to close all the windows, and zero out their coordinates. This may not work if a third party keyboard is in use, for best results, use an Apple keyboard to zero out the coordinates.

Article Change History:

02 Nov 1994 - Added possible problems with third party keyboards.

30 Sep 1994 - Edited to include the words "watch" and "pointer".

Support Information Services

Copyright 1993-94, Apple Computer, Inc.

Keywords: ksts

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 13631