



Tech Info Library

Apple Color Printer: Blank Edge Caused by Letterhead (9/94)

Article Created: 15 September 1994

* RESTRICTED: Apple Internal and Support Providers Only *
Not For General Public Release

TOPIC -----

When I print on my letterhead paper using the Apple Color Printer there is a one-inch column at the left edge of the page that is blank. The blank area corresponds to a dark black patch that is part of the design on my letterhead. The printer has no problems printing on plain white paper.

What is causing the problem? Is there a workaround?

DISCUSSION -----

The Apple Color Printer uses a small photosensor mounted on the carriage assembly to detect the top edge and width of the paper. If the photosensor doesn't receive a reflection then it assumes that there is no paper present. The width calculation is important when using an ink jet printer because it prevents the printer from accidentally depositing ink on the platen and other internal components.

Although inconvenient, placing a small piece of reflective non-stick paper over the left edge of the letterhead prior to printing should prevent the problem from occurring. As long as the non-stick note lays flat on the paper it won't interfere with the operation of the carriage mechanism.

The Color StyleWriter Pro does not use a photosensor to detect paper width and therefore does not have this limitation.

Support Information Services
Copyright 1994, Apple Computer, Inc

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 16283