

## ImageWriter II: Top Pin Is Not Firing (11/94)

Tech Info Library Article Number: 8518

Article Created: 25 June 1991 Article Reviewed/Updated: 10 November 1994
* RESTRICTED: Apple Internal and Support Providers Only * Not For General Public Release
TOPIC
I am having a problem with an ImageWriter II. The top pin is not firing. I have systematically replaced the:
<ul><li>print head</li><li>main logic board</li><li>drive PCB</li><li>print head cable (going to print head)</li></ul>
I have checked all connections along the way and adding shims did not help.
DISCUSSION
Try the color ribbon adjustment for that printer as documented in the Service Source CD. Also try removing the paper guide and printing with it removed. If the upper pin then fires, replace the paper guide.
Article Change History: 10 Nov 1994 - Reviewed for technical accuracy.
Support Information Services Copyright 1991-94 Apple Computer, Inc.
Keywords: hts
This information is from the Apple Technical Information Library.
19960215 11:05:19 00