

Peter & Santa Claus CD: CD Not Seen on Desktop (12/93)

TOPIC
Why can't I see the Peter & Santa Claus CD on my Desktop?
DISCUSSION
One of the following may help you solve your problem:
 Ensure that your CD-ROM drive is turned on & plugged into an active electrical outlet.
 Ensure the CD-ROM drive's SCSI connection is properly connected t your Macintosh (see your CD-ROM drive's manual for instructions).
3) Ensure the CD-ROM drive's SCSI ID does not conflict with another SCSI device's ID number (consult your CD-ROM drive's manual for further information).
4) Ensure all CD-ROM drivers are installed.
5) Ensure the CD-ROM drive has been turned on before the Macintosh has been turned on (with the CD-ROM Player turned on restart your Macintosh).
6) Try to use another CD-ROM. This will narrow down the problem to either the set-up or the CD-ROM disc. It is highly unlikely that the problem involves the disc. Copyright 1993, Apple Computer, Inc
Keywords: <none></none>
-
This information is from the Apple Technical Information Library.
19960215 11:05:19.00
Tech Info Library Article Number: 14132

Article Created: 2 December 1993