



# Tech Info Library

## StyleWriter Printers: Out of Paper Message Troubleshooting 10/96

Article Created: 7 October 1996

TOPIC -----

I keep getting an error message when I try to print from my StyleWriter printer stating that I am out of paper, but the printer has paper in the tray. When I click on Continue, I get an error message stating the paper is there, but it is the wrong size. Why?

DISCUSSION -----

These error messages are usually caused by using an incorrect or damaged printer cable.

First check to make sure that you are using a peripheral-8 cable (serial cable), and not a LocalTalk or PhoneNet cable with the StyleWriter printer. LocalTalk cables and PhoneNet cables, use small boxes along with specialized cable to connect devices. PhoneNet cables resemble telephone cable. You can only use LocalTalk and PhoneNet cables with certain StyleWriter models containing the optional LocalTalk Adapters.

The correct cabling for most StyleWriter printers is peripheral-8 (serial) cable. The serial cable is a direction connection between the computer and the printer. You should not have any type of splitting or adapter devices between the computer and the printer. In addition, the serial cable should have eight (8) straight and intact pins on both ends of the cable.

If you are using a peripheral-8 cable and still experience problems, try connecting the printer to another computer, or try another peripheral-8 cable.

Copyright 1996, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19961008 07:53:05.00

Tech Info Library Article Number: 20511