



Tech Info Library

ImageWriter: First printed line is expanded or crunched

When you print a file on the Imagewriter, sometimes the first printed line at the beginning of the paper is crunched or expanded. This problem sometimes occurs after you take the paper out of the platen: you may have left the tractor gears in a position "between linefeeds". Solve this problem by doing a form feed right every time you reload the printer with paper.

Sometimes the paper is not held tight enough by the rollers, especially when you use cut sheets. Solve the problem by "burping" the printer: turn the printer off and on so the printhead moves back and forth and the gears are tightened.

Owen Densmore, Sep/Oct 1984 issue of Macworld

Keywords: <None>

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 877