



# Tech Info Library

## LaserWriter II: Fuser Temperature, Paper Speed

This article last reviewed: 31 March 1988

When choosing an acetate transparency for use in a LaserWriter II, it is important to consider the temperature of the printer's fuser roller and the amount of time the acetate sheet is in contact with the roller.

The temperature of the LaserWriter II fuser roller varies from:

- 329 to 356 degrees Fahrenheit
- 165 to 180 degrees centigrade

An 8.5" by 11" sheet of paper or acetate takes approximately 5.8 seconds to travel over the fuser roll. This works out to be about 1.5 inches per second.

The LaserWriter II accepts medium weight photocopier transparencies such as Scotch #503, catalog # 15921-3.

Copyright 1988 Apple Computer, Inc.

Keywords: <None>

=====  
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 2763