



Tech Info Library

Portable StyleWriter: How to Charge the Batteries (2/95)

Article Created: 3 October 1994

Article Reviewed/Updated: 7 February 1995

TOPIC -----

Is there a special method for charging the Portable StyleWriter battery? Putting it into the Portable StyleWriter battery compartment and connecting the printer to the AC adapter does not seem to charge it no matter how long I leave it plugged in.

DISCUSSION -----

Follow these steps to place the Portable StyleWriter into battery charging mode:

- 1) Ensure that the power adapter is plugged into a wall outlet and into the printer.
- 2) Check that the battery switch is in the "1" position (versus the "0" position) on the back of the printer.
- 3) Turn on the printer with the Power button while holding down the On Line button.
- 4) When the first beep sounds, release the Power button.
- 5) When the second beep sounds, release the On Line button.

The POWER LED begins flashing, indicating that the printer has entered the battery charging mode.

The battery charging voltage is 14.8 volts DC. The printer controller checks the battery voltage every two minutes during the charging process, which normally takes about 10 hours. When the charging is complete the printer automatically stops charging and turns itself off. If the battery voltage is less than 6 volts DC at any time during the charging process, the battery is either over-discharged or defective, at which time the controller alternately flashes the POWER and ERROR LEDs to indicate a charging problem. The POWER LED flashes when the battery needs recharging.

Article Change History:

07 Feb 1995 - Added additional information; added keyword.

Support Information Services
Copyright 1994-95, Apple Computer, Inc.

Keywords: hts,kalley

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 16429