



# Tech Info Library

## Macintosh Portable: Internal Modem Installation Guide

This article last reviewed: 18 September 1989

All power must be disconnected before the modem can be installed. The AC adapter must be disconnected, the main battery removed and the battery cover must be in place to shut off the backup battery to insure the unswitched +5 volt connection is disconnected. If the power is not completely shut off, the modem may be damaged.

Note: This action will cause all RAM to lose power. This will erase RAM disks, reset all Control Panel settings including the system clock and lose any unsaved documents which are open.

This procedure is also the recommended method to hardware reset the modem.  
Copyright 1989 Apple Computer, Inc.

Keywords: <None>

=====  
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 4479