



# Tech Info Library

## Super Serial Card: Cable for Centronics 737 (11/96)

Article Created: 04 December 84

Article Reviewed/Updated: 20 November 1996

TOPIC -----

Listed below are the cable pinouts for connecting the Super Serial card to a Centronics 737 printer.

DISCUSSION -----

| Super Serial Card (SSC) | Pin           | Cable   | Pin     | Printer Connector |
|-------------------------|---------------|---------|---------|-------------------|
| Frame Ground .....      | (FG)..... 1   | <-----> | 1.....  | (FG)              |
| Transmit Data           | (Tx) ..... 2  | <-----> | 3.....  | (Rx)              |
| Receive Data            | (Rx) ..... 3  |         |         |                   |
| Request to send         | (RTS) .... 4  | <-----> | 6 & 8.. | (DSR) & (DCD)     |
| Clear To Send           | (CTS) .... 5  |         |         |                   |
| Data Set Ready          | (DSR) .... 6  | <-----> | 11      |                   |
| Signal Ground .....     | (SG)..... 7   | <-----> | 7.....  | (SG)              |
| Data Carrier Detect     | (DCD) .... 8  |         |         |                   |
| Secondary Clear To Send | (SCTS) ... 19 |         |         |                   |
| Data Terminal Ready     | (DTR) .... 20 |         |         |                   |

### Article Change History:

20 Nov 1996 - Reviewed for technical accuracy, revised formatting.

Copyright 1984-96, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19961122 07:37:55.00

Tech Info Library Article Number: 928