



Tech Info Library

Super Serial Card: Cable for C.Itoh, C.Itoh F10 (11/96)

Article Created: 04 December 1984

Article Reviewed/Updated: 21 November 1996

TOPIC -----

Listed below are the cable pinouts for connecting the Super Serial card to a C.Itoh or C.Itoh F10 printer.

DISCUSSION -----

C.Itoh Printer

Super Serial Card (SSC)	Pin	Cable	Pin	Printer Connector
Frame Ground(FG).....	1	<----->	1.....	(FG)
Transmit Data (Tx)	2	<----->	3.....	(Rx)
Receive Data (Rx)	3			
Request to send (RTS)	4			
Clear To Send (CTS)	5			
Data Set Ready (DSR)	6	<----->	20.....	(DTR)
Signal Ground(SG).....	7	<----->	7.....	(SG)
Data Carrier Detect (DCD)	8			
Secondary Clear To Send (SCTS) ...	19			
Data Terminal Ready (DTR)	20			

* Check C.Itoh owners manual for additional information on setting the printer's option jumpers.

C.Itoh F10 Printer

Super Serial Card (SSC)	Pin	Cable	Pin	Printer Connector
Frame Ground(FG).....	1	<----->	1	(FG)
Transmit Data (Tx)	2	<----->	3	(Rx)
Receive Data (Rx)	3	<----->	2	(Tx)
Request to send (RTS)	4	<----->	8	(DCD)
Clear To Send (CTS)	5	<----->	8	(DCD)
Data Set Ready (DSR)	6	<----->	20	(TDR)

Signal Ground(SG)..... 7 <-----> 7(SG)
Data Carrier Detect (DCD) 8 <-----> 4 & 5 .(RTS) & (CTS)
Secondary Clear To Send (SCTS) ... 19
Data Terminal Ready (DTR) 20 <-----> 6(DSR)

* Use printer at 1200 Baud.

Article Change History:

21 Nov 1996 - Reviewed for technical accuracy, revised formatting.

Copyright 1984-96, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19961122 07:37:55.00

Tech Info Library Article Number: 929