Apple II Plus: Relocation/Configuration Error (2/97)

Article Created: 02 July 1991
Article Reviewed/Updated: 17 February 1997

TOPIC ---

What is the meaning of a relocation/configuration error on the Apple II Plus
when running ProDOS?

DISCUSSION --

ProDOS requires 64K of RAM to run. The error you are getting means that you have
only 48K of RAM.

Article Change History:
17 Feb 1997 - Reviewed for technical accuracy, revised formatting.

Copyright 1991-97, Apple Computer, Inc.

Keywords: <None>

==

This information is from the Apple Technical Information Library.

ArticleID: TECHINFO-0007803

19970218 12:34:27.00

Tech Info Library Article Number: 7803