

Apple IIGS: Booting From an AppleShare Server (7/94)

Article Created: 14 July 1994

TOPIC -----

I have an Apple IIGS, and it does not boot properly from an AppleShare server. How can I boot the Apple IIGS from the server?

DISCUSSION -----

This problem only happens with Apple IIGS computers that have ROM 01. There are two solutions:

- 1) Upgrade to ROM 03. It doesn't have a problem booting from an AppleShare server.
- 2) Create an AppleShare boot disk and start the Apple IIGS from that disk.

This allows you to use the Auto Logon feature to set the boot disk to automatically log into the server and launch a program at startup.

Support Information Services Copyright 1994, Apple Computer, Inc

Keywords: hts, ksts

This information is from the Apple Technical Information Library.

19960215 11:05:19.00 Tech Info Library Article Number: 15818