



# Tech Info Library

## Apple IIe Keyboard: Defeating The Keyboard Auto Repeat

Article Created: 21 September 1984

Article Last Reviewed: 23 April 1991

Article Last Updated: 25 May 1989

Disabled persons want to know how to defeat the repeat function of the Apple IIe keyboard so that it's easier to use. The following procedure defeats the repeat function without changing the keyboard in any other way.

Exercise caution. The following procedure may void the warranty on the Apple IIe.

- 1) Remove the main logic board from the case.
- 2) Locate the large IC just below the keyboard connector, location D14.
- 3) Carefully remove the IC.
- 4) Locate the small dot or indentation on the corner of the IC and from there count up to pin 5.
- 5) Carefully bend pin 5 out from the IC.
- 6) Carefully reinsert the IC into the logic board. Make sure that pin 5 is the only pin not inserted and that no other pins are bent.
- 7) Reinstall the logic board into the case.

Try the repeat function. It should not operate.

Copyright 1988, 1991 Apple Computer, Inc.

Keywords: <None>

=====  
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 268