



Tech Info Library

Apple IIe: AppleTalk Workstation Card and Printing

This article last reviewed: 29 November 1988

To print to a serially-connected ImageWriter through the AppleTalk Workstation Card on an Apple IIe:

1. Place the AppleTalk Workstation Card in any Apple IIe slot.
2. Start up the system with the Workstation disk. (If there are no disks in the drives, the system starts up over the network with a slight delay.)
3. Select Chooser.
4. Using the Chooser, select the locally-connected serial printer. (Local printers and AppleTalk printers are shown on separate lists.)
5. Ensure that the printer is connected to the printer port on the AppleTalk Workstation Card.
6. Set the application to print to the slot that the Workstation Card is in.

Copyright 1989 Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 3480