



Tech Info Library

Apple IIe: How To Connect To An AppleShare Network

This article last reviewed: 1 November 1988

An unenhanced Apple IIe requires the Apple IIe Enhancement kit (consisting of new ROMs and CPU), the Apple Workstation card, and 128K RAM to be connected to an AppleShare network.

An enhanced Apple IIe requires only the Apple Workstation card and 128K RAM.
Copyright 1988 Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 3434