



Tech Info Library

AppleWorks 2.0: Booting it on the Apple IIe

You MUST have an Extended-80 Column card installed in the Apple IIe to boot AppleWorks 2.0, even if you have a 1 Megabyte Memory Expansion Card installed. AppleWorks 2.0 requires a 128K Apple IIe or Apple IIc to boot and does not recognize the IIe unless you have the Extended-80 Column Card.
<None>

Keywords: <None>

=====
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 174