



Tech Info Library

AppleWorks IIe: Connecting a NEC 3510 letter quality printer

A. Apple IIe

1. Super Serial Interface Card settings:

	1	2	3	4	5	6	7		1	2	3	4	5	6	7
ON			X	X	X			ON	X	X					X
SW1								SW2							
OFF	X	X	X		X			OFF		X	X	X	X		
	1	2	3	4	5	6	7		1	2	3	4	5	6	7

-- Jumper block points to TERMINAL

2. AppleWorks settings

a. Carriage: 11"

b. Linefeed after carriage return: YES

c. Underlining: The NEC 3510 LQP makes an underlines by printing the character, backspacing one character, and printing the underline.

d. Special Codes

-- Check the printer manual.

Begin End

1. Boldface: Esc * Carriage Return

2. Underline: Esc - Esc '

3. Superscript: Esc ; Esc :

4. Subscript: Esc : Esc ;

5. Proportional Spacing 1: Esc H Esc I

B. Cabling

Super Serial
Interface Card NEC 3510

DB-25 DB-25

2 2
3 3
7 7
19 19

C. NEC 3510

1. Switch settings

a. Front panel

1 - Off
2 - Off
3 - On
4 - Off
5 - On
6 - Off
7 - Off
8 - Off

b. Back panel

1 - Off
2 - Off
3 - Off
4 - Off

-- 9600 baud, no parity, 8 data bits, 1 stop bit
Apple Technical Communications

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 1783