



Tech Info Library

AppleWorks: Using it with the IIfx and the Epson DX-20 printer

This article describes how to run AppleWorks on a IIfx with an Epson DX-20 printer.

Configuration:

```
--Apple IIfx
--Super Serial Card
--CompuCable, P/N MTB0201
--Epson DX-20 Letter Quality Printer
--AppleWorks, version 1.3
```

Super Serial Card switch settings:

```
SW 1-1: OFF      SW 2-1: ON
SW 1-2: ON       SW 2-2: OFF
SW 1-3: ON       SW 2-3: OFF
SW 1-4: ON       SW 2-4: OFF
SW 1-5: ON       SW 2-5: ON
SW 1-6: ON       SW 2-6: OFF
SW 1-7: ON       SW 2-7: OFF
```

DX-20 switch settings:

```
SW 1-1: OFF      SW 2: all OFF
SW 1-2: OFF
SW 1-3: ON
SW 1-4: OFF
SW 1-5: OFF
SW 1-6: ON
SW 1-7: OFF
SW 1-8: OFF
```

AppleWorks configuration:

```
Needs line feed after each return: NO
Accepts top-of-page commands:      NO
Stop at end of each page:          YES or NO (NO is preferable)
Platen width:                      13.0
Printer codes:
  Characters per inch: no codes
  Lines per inch: no codes
Boldface, subscript and superscript:
```

Boldface begin: ESC-W
Boldface end: ESC-&
Subscript begin: ESC-U
Subscript end: ESC-D
Superscript begin: ESC-D
Superscript end: ESC-U
Underlining (printer has start/stop underlining commands):
Underlining begin: ESC-E
Underlining end: ESC-R
Apple Technical Communications

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 1914