

Apple IIGS: How To Disable Keyboard Repeat

This article last reviewed: 8 January 1988

People with limited motor skills sometimes can't adapt to the keyboard repeat rate on the Apple IIGS, causing several characters appear after each keypress.

The keyboard repeat rate can be set from the Control Panel. Here's how to disable keyboard repeat altogether:

1. In the Control Panel, select the Options menu.

The 'repeat delay' option controls the time between the first keypress and the time when keys begin auto repeating.

- 2. To disable the auto repeat feature, move the asterisk all the way to the left of the sliding scale.
- 3. To save the changes made to the Control Panel, press Return. Copyright 1989 Apple Computer, Inc.

Keywords: <None>

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 2047