

## Apple IIe: Stopping the blink of the cursor

There are two ways to stop the blinking cursor on the IIe.

- 1. If you have an 80-column card, do a PR#3 and then an ESC 4. This uses the 80-column firmware but in 40-column mode.
- 2. If there is no 80-column card installed on your system, do a POKE 49162,0:PRINT CHR\$(4)"PR#3". This has the same effect.

In the  $80\mbox{-}\mathrm{column}$  firmware, the cursor is an inverse blank. This effectively removes the flashing cursor.

Apple Technical Communications

Keywords: <None>

\_\_\_\_\_\_

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 844