

DOS: Version 3.3 and the language card

At power up, DOS 3.3 looks at location \$E000, both on the motherboard and on the firmware card, to check which version of BASIC is available. If a Language card is present, DOS tries to jump into some random information on the card. This jump is prevented by a machinge language routine that places a \$00 at \$E000 on the Language card during booting. This routine is stored on the DOS diskette at track 0, sector 9, starting at byte \$D3 Apple Tech Notes

Keywords: <None>

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 565