

## DOS Compatibility Card: No Video When Changing OS (1/96)

Article Created: 9 January 1996

TOPIC -----

I have a DOS Compatibility Card in my Macintosh computer, and when I press the Command/Return key combination on my keyboard to change to MS-DOS/Windows, the screen dims, but I don't get the MS-DOS prompt. Why?

DISCUSSION -----

The most common cause of this is the video cable. If the DOS Compatibility Card video cable is not securely fastened to monitor cable and DOS Compatibility Card, or you do not have the DOS Compatibility Card video cable connected properly, the screen dims, but you will not see the MS-DOS prompt.

You should check the cable connections, and then restart your Macintosh computer. If you do not restart your computer, the monitor will not sync properly. This is because when the PC Setup control panel loads it determines what monitor is connected. When it cannot determine what monitor is connected, the PC Setup control panel defaults to an Apple 16-in. Display setting.

Support Information Services Copyright 1996, Apple Computer, Inc.

Keywords: kwindows

\_\_\_\_\_

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 19194