

DOS Compatibility Card: Ethernet Drvr Does Not Use IRQ's (2/95)

Article Created: 6 February 1995

TOPIC -----

I need to know the Ethernet IRQ settings for the DOS Compatibility Card. I have a DOS application that needs to know the IRQ settings.

DISCUSSION -----

The ethernet driver (MACODI.COM) used for the built-in Ethernet on the DOS Compatibility Card does not use IRQs. It conforms to the ODI specification for a Multiple Link Interface Driver (MLID), which do not use IRQs. You are probably trying to use a NDIS application, whose drivers DO use IRQs. If this is the case, you need to use Novell's ODI to NDIS translator (odinsup.com) to configure the software to function in an ODI environment. For more information on odinsup.com, contact Novell Inc.

To locate a vendor's address and phone numbers, use the vendor name as the search string.

Support Information Services Copyright 1995, Apple Computer, Inc

Keywords: kwindows

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 17127