

AppleTalk Remote Access: Network adev (Remote Only)

| Article Created: 15 October 1991 Article Last Reviewed: Article Last Updated: |
|---|
| TOPIC |
| What is the AppleTalk Remote Access Remote Only adev? |
| DISCUSSION |
| The Remote Only adev (AppleTalk device) is installed in the Extensions folder and appears in the Network CDev. You can disconnect from the local network and see only the remote network. Here are two situations where you might need to do this: |
| - In the Event of a Network Number Conflict |
| When a resource on the remote network has the same number as a resource on the local network, you can access the remote resource using the Remote Only adev. |
| - When You Have a Printer Port, and No Other Network Connections |
| When you must use the printer port for something other than AppleTalk, you can use the Remote Only adev to free up the printer port. For example, a non-networked Macintosh with a serial printer connected to the printer port and a modem connected to the modem port. Copyright 1991 Apple Computer, Inc. |
| Keywords: <none></none> |
| This information is from the Apple Technical Information Library. |

19960215 11:05:19.00

Tech Info Library Article Number: 8943