

AppleShare PC 2.0: Not Recommended on Single-Drive PC

11110	ar crore	Lab c	TCVICWCa		00	CODCI					
TOPIO	C										
When	installi	na Ar	opleShare	PC	on	a macl	nine	with	one	5.25-inch	disk

When installing AppleShare PC on a machine with one 5.25-inch disk remember that it really has two logical drives, A: and B:. To test this at DOS, issue this command:

DISKCOPY A: B:

The DOS DISKCOPY program prompts you to switch disks with a message like

"Please insert the diskette for drive A:."

This article last reviewed: 13 October 1989

Because I haven't had a chance to use AppleShare PC 2.0, I don't know how the installer batch file is written. If it asks for drives by drive letter, I'd try specifying A: and B: and let DOS ask you to do a disk swap.

DISCUSSION -----

You are correct that the AppleShare PC 2.0 installer can install from A: to B:--even when B: is just a logical drive. DOS prompts for each disk as it is needed. Unfortunately, because of the installer program's design, this might require swapping disks as many as 100 times--even for print services alone.

This means that we do not recommend installing AppleShare PC 2.0 using a system that has only one floppy drive and no a hard disk. Booting such a system with already installed disks works fine. However, unless you enjoy swapping disks, don't try to install on it.

As a side note, the installer is actually an executable file, not a batch file. You can write a batch file to do the install by using the xcopy command on groups of files. This shortens the install process a great deal and allows installing with a single drive PC. Of course, it also requires manual preparation of AUTOEXEC.BAT and NET.CFG and selection of the proper REDIR file, depending on what version of DOS is being used. Copyright 1989 Apple Computer, Inc.

Keywords: <None>

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 4782