



Tech Info Library

AppleShare PC: Minimum Files Needed for File Services

This article last reviewed: 28 November 1990

TOPIC -----

What is the bare minimum for AppleShare/PC files needed to access FILE SHARING only? The following is the list of files I am currently loading, and I need to free up at least 60K of RAM:echo off.

```
C:\ASPC\LSL
C:\ASPC\ENET3CII /NAME=ETHER$
C:\ASPC\AARP
C:\ASPC\ATALK
C:\ASPC\ASP_WS
C:\ASPC\AppleShare
C:\ASPC\MINSES
C:\ASPC\REDIR
C:\ASPC\ANET AUTO
```

Any chance I could take some of these out?

DISCUSSION -----

You have the minimum files necessary for what you want. Depending on the type of hardware you are using, it may be possible to load some parts of AppleShare PC into high memory (you need a 386 machine with a minimum of 1MB of RAM). This would free up more than the 60K that you are looking for.

If you want to check the files you do have, you could re-run the Installer and specify file services only, that will install the minimum set.
Copyright 1990 Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 6433