



Tech Info Library

Express Fax Modem: Fax Icon Crossed Out (8/93)

Article Created: 3 August 1993

TOPIC -----

When I boot up on my PowerBook Duo, the Fax INIT for my Apple Express Fax Modem appears with an X through it. The modem INIT still works fine, but I can't send faxes.

DISCUSSION -----

It sounds like an earlier system crash corrupted the Express Fax Preference file. You can fix it by throwing away the Fax Terminal Preference file in the System Preferences folder. You can restore it from the original software disks.

This problem was common to early versions of Apple Express Fax software, but has since been corrected in the 1.0.4 version.

Support Information Services
Copyright 1993, Apple Computer, Inc

Keywords: KSTS, Kpbook

=====
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 12859