



# Tech Info Library

## **ANAT: Unable to Initialize At Ease Server (9/96)**

Article Created: 25 September 1996

TOPIC -----

I have Apple Network Administrator Toolkit (ANAT), and I just installed At Ease 4.0 server software on my AppleShare server. When I restart the server, I get a message that states "Unable to Initialize At Ease Server."

DISCUSSION -----

You may receive this message if you did not setup the AppleShare server prior to installing At Ease server. You will need to go into AppleShare Admin and setup the Admin Key. Restart the server and At Ease server will load correctly.

Copyright 1996, Apple Computer, Inc.

Keywords: katease,kanat,kalley

=====

This information is from the Apple Technical Information Library.

19960926 07:13:27.00

Tech Info Library Article Number: 20459