



Tech Info Library

Network Server LCD Values: Manual Correction (6/96)

Article Created: 20 March 1996

Article Reviewed/Updated: 6 June 1996

TOPIC -----

This article describes a "Using AIX, AppleTalk Services, and Mac OS Utilities on the Apple Network Server" manual correction.

DISCUSSION -----

Below is a corrected version of the table on page 161, Chapter 10 Troubleshooting, of the "Using AIX, AppleTalk Services, and Mac OS Utilities on the Apple Network Server" manual. These are the values displayed during a normal system startup.

Begin_Table

| LCD | System Action |
|-----|---|
| 510 | The system has started the configuration manager. |
| 511 | The configuration manager has completed. |
| 517 | The system is attempting to mount the / (root) and /usr file systems. |
| 538 | The configuration manager is passing control to a configuration method. |
| 539 | The configuration method has completed. |
| 551 | The system is attempting to vary on the root volume group. |
| 553 | The system has completed phase one of the boot process. |
| 591 | The system is configuring the Logical Volume Manager (LVM). |
| 593 | The system is configuring the low-function graphics terminal. |
| 594 | The system is configuring the rendering context manager. |
| 704 | The system is configuring a SCSI disk drive. |
| 723 | The system is configuring a CD-ROM or other SCSI device. |
| 727 | The system is configuring an asynchronous device. |
| 731 | The system is configuring a pseudo TTY. |
| 811 | The system is configuring the system planar (mainboard). |
| 812 | The system is configuring the standard I/O adapter. |
| 814 | The system is configuring the NVRAM. |
| 821 | The system is configuring the standard keyboard adapter. |
| 823 | The system is configuring the standard mouse adapter. |
| 826 | The system is configuring on-serial port 1. |
| 828 | The system is configuring the standard floppy disk adapter. |

831 The system is configuring serial port 2.
868 The system is configuring the integrated SCSI adapter.
874 The system is configuring the graphics subsystem adapter.
921 The system is configuring a keyboard.
925 The system is configuring a mouse.
935 The system is configuring a 3.5-inch diskette drive.
9002 The system is configuring a SCSI-2 adapter.
c301 Apple Desktop Bus (ADB) time out.

End_Table

Article Change History:

06 Jun 1996 - Added another LCD code.

Copyright 1996, Apple Computer, Inc.

Keywords: kmanerr

=====

This information is from the Apple Technical Information Library.

19960606 16:20:01.00

Tech Info Library Article Number: 19497