

## **Macintosh Internal Drive**

Article Created: 17 January 1986 Article Last Reviewed: 17 July 1992 Article Last Updated: 17 July 1992

PROBLEM DESCRIPTION: The Macintosh Internal Drive will not operate even though a new exchange module has been connected.

CAUSE: The drive is not secured to the chassis.

CURE: Always make sure that the drive is screwed securely to the chassis when troubleshooting for internal drive problems.

Follow General Troubleshooting Procedures if the drive is screweed to the chassis and still does not work.

Copyright 1988, 1992 Apple Computer, Inc.

Keywords: hts

\_\_\_\_\_\_

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 2068