



Tech Info Library

LaserWriter: Laser Power Adjustment

This article last reviewed: 10 November 1988

When the laser is replaced in a first-generation LaserWriter (LaserWriter and LaserWriter Plus), the laser power must be adjusted by a pot on the DC controller board.

In the LaserWriter II, there is no pot on the DC controller board. Power adjustment is not needed during laser replacement.
Copyright 1988 Apple Computer, Inc.

Keywords: <None>

=====
This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 2930