

Personal LaserWriter: Using Overseas

Tech Info Library Article Number: 7796

| This article last reviewed: 15 July 1990 |
|--|
| TOPIC |
| Is a step-down transformer required for using a Personal LaserWriter overseas? It appears that it does because on the back of the printer it states 100-115v at 50-60 Hertz. Also, why does the printer specification sheet give both US/Japan and European/Australian power requirements? |
| DISCUSSION |
| As with our other LaserWriter printers, there are voltage-specific versions available. There are actually two different Personal LaserWriters versions: one for the US/Japan market and the other for the European/Australian market. |
| You do need a step-down transformer if you take a Personal LaserWriter overseas, just as you would for any LaserWriter or LaserWriter II. Copyright 1991, Apple Computer, Inc. |
| Keywords: <none></none> |
| |
| This information is from the Apple Technical Information Library. |
| 19960215 11:05:19.00 |