



# Tech Info Library

## Lisa: Error 38 is No Boot File on Disk

Article Created: 14 May 1991

Article Last Reviewed: 27 May 1991

Article Last Updated:

### TOPIC -----

When I try to boot a MacWorks disk on my Lisa, I get an error code 38.

This error is placed under an icon with a check in it. It only accesses the floppy for a brief moment and then gives the error code. It then prompts me to continue or to choose a startup device (STARTUP FROM...). When I continue, the above occurs again, over and over. If I choose a startup device, it gives me the option of the floppy only -- not the HD.

What's going on?

### DISCUSSION -----

Error 38 is "No Boot File on Disk." It sounds like the MacWorks disk was erased. If the disk was good to begin with, you have a hardware problem with the floppy drive.

Copyright 1991, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 8153