

## Lisa: Line Frequency

The Lisa hardware manual wrongly states that the line frequency should be 60 Hz +/- 2. The actual number is 50-60 Hz +/- 2, which covers most reasonable power sources. This is true of all Lisa 2s. Apple Technical Communications

Keywords: <None>

\_\_\_\_\_\_

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 797