Lisa/Macintosh XL: RS-232 and RS-422 Pinouts for Serial Port B

The signals available on Serial Port B of the Lisa are shown in
Figure 3-9, page 3-24 of the Lisa Hardware Manual (for RS-232) and
on page 3 of Macintosh Technical Notes #10 (for RS-422). This data is
combined here.

```
Pin No.   RS-232 Name              RS-422 Name      Notes

1         Ground                   Ground
2         Transmit data            TxD-
3         Receive data             RxD-
4         Request to send
6         Data set ready           HSK/DSR          TRxCB or CTSB
7         Ground                   Ground
19        AppleTalk receive data   RxD+
20        Data terminal ready      TxD+/DTR         Connected to DTRB
<None>
```

Keywords: <None>

==

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 801