



Tech Info Library

Imagewriter: Configuring for a Lisa

Article Created: 26 September 1985

Article Reviewed/Updated: 17 October 1994

TOPIC -----

The following information shows how to configure a Lisa and an ImageWriter printer.

DISCUSSION -----

Cables:

--From back of machine: Modem Eliminator Cable (Part #590-0166)

--From printer: Serial and Communications Cable (Part #590-0037)

The loose end of these two cables are then joined.

Printer Switch Settings:

```
      8 7 6 5 4 3 2 1
SW1: | | |X| | | | |
      |X|X| |X|X|X|X|X|
```

```
      4 3 2 1
SW2: | | |X|X|
      |X|X| | |
```

Article Change History:

17 Oct 1994 - Reviewed for technical accuracy, revised formatting.

Support Information Services

Copyright 1984-94 Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 1097