Lisa 7/7: Printing Executive PS on a DWP

When you select to print a document on a Daisy Wheel Printer in Executive PS,
the printer sometimes simply ejects a blank page. If this occurs, select Elite
12, Courier 10 or Gothic 15 instead; your DWP will then print properly.
Apple Technical Communications

Keywords: <None>

===

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 887