

Apple Video Player: Read Me (4/95)

Article Created: 5 April 1995

TOPIC -----

This article contains the Apple Video Player ReadMe file.

DISCUSSION -----

Important Information About Apple Video Player

This document provides important information about the Apple Video Player software. You may want to print this document and keep it with your manuals. Most of this information is not in the documentation. If you have questions that are not answered in this document, refer to the manuals that came with your computer.

After you finish reading this document, you can close it by clicking the small box at the upper left of the document window, by typing Command-Q, or by selecting Quit from the File menu.

Video Quality

Video viewing and video capture is supported in window sizes of up to 640 x 480 pixels. For the highest-quality video and TV viewing, use the standard video window sizes (Smallest, Normal, or Largest) in Apple Video Player's Windows menu. If you choose to customize the window size (by choosing Other in the Windows menu), the image's resolution may decrease.

In addition, video resolution is optimized when you view the Apple Video Player video window on the monitor connected to the monitor port on your Macintosh. You can drag the video window to a secondary monitor (connected to an expansion card), but the image resolution will decrease.

Hot Key and MacroMedia Director

The Apple Video Player application program allows you to use a keyboard shortcut, called a "hot key," to open and quit the program, and to switch between Apple Video Player and any other open programs. However, due to a minor

incompatibility problem with MacroMedia Director, the Apple Video Player hot key doesn't work when MacroMedia Director is open.

If you are installing Apple Video Player for the first time, no hot key is defined. You can set one using the Hot Key item in the Setup Menu. If you are replacing a previous version of Apple Video Player, the hot key setting is retained in the Apple Video Player Preferences file.

Closed Captioning

If you have a TV tuner card, the Apple Video Player application program can display closed captions for TV channels that provide them. However, in order for closed captions to be visible, the video window size must be set to Normal Size or greater. Also, for best results, networking or printing should not be active when close captioning is selected.

Capturing Movies

Likewise, for best results, networking or printing should not be active when you are recording video from either television or an alternate video source. Virtual memory should also be turned off when capturing video for best results.

Forgetting Your Password

If you can't remember your password, you may reset the password by removing the Apple Video Player Prefs file. To remove the Apple Video Player Prefs file, quit Apple Video Player and move the Apple Video Player Prefs file to the Trash. The Apple Video Player Prefs file is located in the Preferences folder, which is in the System Folder.

Support Information Services Copyright 1995, Apple Computer, Inc.

Keywords: <None>

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 17535