



Tech Info Library

Color Classic: Front Panel Controls (2/93)

Article Created: 9 February 1993

TOPIC -----

What do the buttons on the front of my Macintosh Color Classic do?

DISCUSSION -----

The Color Classic has two functional buttons on the front bezel:

- The control to the far right adjusts both the brightness and contrast of the display.
- The control to the far left adjusts the system's sound volume.

The changes you make with these controls are reflected in the Screen and Monitor control panels.

The plastic button labeled "Color Classic" (or, in Europe, "Colour Classic") is only a nameplate, not a functional button.

Copyright 1993, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 11441