



Tech Info Library

ImageWriter II: Troubleshooting Printer is not responding

Article Created: 18 April 1991
Article Last Reviewed: 29 July 1992
Article Last Updated:

TOPIC -----

I'm using an ImageWriter II with a Macintosh Portable. I keep getting the message. "Printer is not responding. Check the select switch", but my select switch is on.

DISCUSSION -----

If there is nothing wrong with your ImageWriter II, there are three possible causes for this problem:

- A defective printer cable.
- A defective printer port on the Macintosh Portable.
- Incorrectly set software.

The most common of the three causes is incorrectly set software. Be sure you have selected the proper ImageWriter driver--not the AppleTalk ImageWriter--in the Chooser, and confirm that it is in the selected port, either printer or modem.

Copyright 1991, Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 7391