



Tech Info Library

Macintosh Portable: Don't Ignore Battery Icon

Article Created: 13 August 1991
Article Last Reviewed: 29 July 1992
Article Last Updated:

TOPIC -----

How can I remove the battery icon that appears in the upper right hand corner of my Macintosh Portable screen? It interferes with "Balloon" Help and my SuperClock. I can't seem to find a way of controlling its presence in the menu bar.

DISCUSSION -----

One reason for the icon's appearance is running the battery desk accessory; the Application Menu icon will show the DA's battery icon (in the top right corner).

Another possibility is that the battery is low, and the battery DA is flashing its icon as a notification to recharge.

Before you try to suppress it, it's important to know whether it's telling you something important.

Copyright 1991 Apple Computer, Inc.

Keywords: <None>

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 8645