



Tech Info Library

PowerBook: Using AppleTalk Remote Access with Internal Modem

Article Created: 13 February 1992

TOPIC -----

How do I configure AppleTalk Remote Access to use my Macintosh PowerBook 170 internal modem? There is no option in the AppleTalk Remote Access Setup to choose the internal modem.

DISCUSSION -----

You need to configure both the AppleTalk Remote Access Setup and the Macintosh PowerBook Portable control panel to use the internal modem.

- 1) In the AppleTalk Remote Access Setup, select the Modem port.
- 2) From the Apple menu, choose Control Panels and select the Portable control panel.
- 3) In the Portable control panel, you have the option to set the serial port for either the external or internal modem. Set the port for the internal modem (note that this will disable the external serial modem port).

Support Information Services
Copyright 1992 Apple Computer, Inc.

Keywords: KPBook

=====

This information is from the Apple Technical Information Library.

19960215 11:05:19.00

Tech Info Library Article Number: 9868