



# Tech Info Library

## PowerBook 180c: Won't Power Up Properly (12/96)

Article Created: 9 May 1996

Article Reviewed/Updated: 9 December 1996

TOPIC -----

My PowerBook 180c will not always fully power on. It gets a startup chime and I see the screen for a few seconds and then it just shuts down. I have reset the power manager, but that did not correct it. I have a good AC adapter that I checked with my PowerBook 165c. If I charge the battery, it will eventually start the unit, but it will not start with just the AC Adapter.

DISCUSSION -----

You need to make sure you are using the proper AC adapter. If your PowerBook 180c has a modem and a large RAM card, it may require more power than most AC adapters provide. The PowerBook 180c requires a 24W AC adapter. The proper Apple AC adapter can be identified by the Model number M5652, and reads 24W on the AC Adapter tip. If you are using any other AC Adapter and your battery is low, then your PowerBook will not always startup properly without a fully charged battery.

Article Change History:

09 Dec 1996 - Reworded for clarity.

Copyright 1996, Apple Computer, Inc.

Keywords: kpbook

=====

This information is from the Apple Technical Information Library.

19961210 08:29:00.00

Tech Info Library Article Number: 19755